



## Catalogue

# Standard Equipment for Liquefied Gas Tank Containers





# **CONTENTS**

# **Standard Equipment for Liquefied Gas Tank Containers**

Catalogue

Internal Relief Valve	3
Design Options: Internal Relief Valves: T50 Tank Containers	5
80mm Internal Gas Relief Valve with Burst Disc Holder	7
80mm Internal Gas Relief Valve (Cutaway Flange)	9
Discharge Valve Assembly	11
Design Options: Gas Discharge Valve Assembly: T50 Tank Containers	13
2" Short Profile Gas Discharge Valve Assembly	15
Accessories	19
ACME Outlet Assemblies	21
Burst Discs	22
Pressure Gauges	24
Appendix	
Bolt Torque Guide & Step Loading Procedure	27
Client Responsibilities	29
Fort Vale Worldwide	31



# **Internal Gas Relief Valves**









#### Internal Gas Relief Valves: T50 Tank Containers

**Design Options** 


#### **Function**

An 80mm internal gas relief valve is installed in the vapour space of a liquefied gas tank. It is spring-loaded and pre-set to be compatible with the service conditions and it vents to protect the tank from accidental over-pressure. Internal gas relief valves have a high flow performance to prevent the catastrophic failure of a tank.

We offer a range of internal relief valves for different service conditions and flow requirements. Contact us for more information.

#### **Design Options**

The design options below are available on our standard range of 80mm internal gas relief valves.



Flanged: a selection of drilling patterns is available

Style: cutaway flange compatible with a burst disc holder (as above)

or full flange - no burst disc



#### **Pressure Setting**

From 6.9 Bar to 38.5 Bar

#### **Spring Set**

Stainless steel

Special service conditions: Special alloys



#### **Internal Gas Relief Valves: T50 Tank Containers**

#### **Design Options**

#### **Related Parts**

We recommend our range of compatible accessories:

- 89mm reverse-acting burst discs a selection of burst pressures is available (Note)
- Pressure gauges
- Emergency blanking cap to seal a relief valve pressure plate until maintenance is possible
- Gaskets
- Fasteners

**NOTE:** An 89mm burst disc will decrease the flow capacity of an internal gas relief valve by 1%. Make sure that the decreased flow capacity will give sufficient protection to your vessel/system.

Please contact us for more information about these parts.

#### **Relief Valves for Dedicated Service**

We offer a range of relief valves for these service conditions and special cargoes:

- T50 tank containers for liquefied gas
- Rail tank wagons
- U.S. tank trucks
- IBCs and small capacity tanks
- Steam-heating systems for tanks
- Hygienic service
- Food grade for liquid flow

Please contact us for more information about these valves.



#### 80mm Internal Gas Relief Valve with Burst Disc Holder

Part No: 015/2XXXX5 - Metric Setting



#### **Specification**

Nominal size

**DN80** 

Tank connection

Flanged: 8 x 26mm holes on a 220mm PCD

Set pressure

From 6.90 Bar to 34.80 Bar

**Materials** 

Contact parts: 316 stainless steel

Pressure seal: RTFE Tank seal: PTFE

Alternatives are available, refer to the Design Options page

#### **Design Conditions**

Weight: 30.5 Kg
Design Pressure (MAWP): 34.80 Bar
Test Pressure: 52.24 Bar
Design Temperature Min: -40°C
Design Temperature Max: 65°C

**NOTE:** The Design Temperature limits refer to metal parts only. The Design Conditions and Section View dimensions are for the specified part number only.

**Design Codes** BS EN 14129 Obeys TPED, ADR, UKCA

**Design Approval** LRQA


#### **Related Parts**

Description	Part No.
PTFE gasket	5005-812
Pressure gauge: 0-20 Bar *Note	92X/20XXXX
Pressure gauge: 0-40 Bar *Note	92X/40XXXX
Pressure gauge: 0-60 Bar *Note	92X/60XXXX
Emergency blank cap: 015/ series valve**	015/0070X
Emergency blank cap: 005/ series valve**	005/0060X

**NOTE:** The specification changes the part no.

\*\*IMPORTANT: Emergency blank caps have a pressure limit. Check with Fort Vale for compatibility.

#### **Section View**






#### 80mm Internal Gas Relief Valve with Burst Disc Holder

Part No: 015/2XXXX5 - Metric Setting

#### **Parts Drawing**



#### **Parts List**

1 M20 lock nut 5112-036 ○ 2 Cowl retaining washer 055/0135 □ ○ 3 Cowl 055/0130 ○ 4 M20 full nut 5112-033 ○ 5 M20 spring washer 5113-016 6 Poppet head 055/0127 ○ 7 RTFE main seal 5005-825 □ ○ 8 Neoprene O ring 5005-995 □ ○ 9 Poppet stem assembly 055/0120X ○ 10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	Item	Description	Part No.	
3 Cowl	1	M20 lock nut	5112-036	0
5 M20 spring washer 5113-016 6 Poppet head 055/0127 ○ 7 RTFE main seal 5005-825 □ ○ 8 Neoprene O ring 5005-995 □ ○ 9 Poppet stem assembly 055/0120X ○ 10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	2	Cowl retaining washer	055/0135	<u> </u>
5 M20 spring washer 5113-016 6 Poppet head 055/0127 ○ 7 RTFE main seal 5005-825 □ ○ 8 Neoprene O ring 5005-995 □ ○ 9 Poppet stem assembly 055/0120X ○ 10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	3	Cowl	055/0130	0
5 M20 spring washer 5113-016 6 Poppet head 055/0127 ○ 7 RTFE main seal 5005-825 □ ○ 8 Neoprene O ring 5005-995 □ ○ 9 Poppet stem assembly 055/0120X ○ 10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	4	M20 full nut	5112-033	0
7       RTFE main seal       5005-825 □ ○         8       Neoprene O ring       5005-995 □ ○         9       Poppet stem assembly       055/0120X ○         10       M16 full nut (8)       5112-003 ○         11       M16 spring washer (8)       5113-012         12       Body weld assembly       055/0207         13       Top spring locator *Note       055/0116X         14       Spindle guide bush       055/0115 □ ○         15       Stop collar       055/0125 ○         16       Retaining ring clip       055/0114 □ ○         17       Spring pair *Note       8104-XXXXX         18       Bottom spring locator *Note       055/0110X         19       Spring retainer       055/0020 ○         20       M16 stud (8)       055/0025 ○         21       M6 set screw       5111-133 ○         22       Ferrule       SF1.5 ○         23       Anti-tamper wire       6110-119 ○         24       PTFE gasket       5005-826 □ ○         25       11mm ball       055/0031         26       Spring       5104-115 ○         27       Ball seal       055/0030 ○         28       ½" BSP taper plug	5	M20 spring washer	5113-016	
8 Neoprene O ring 5005-995 □ ○ 9 Poppet stem assembly 055/0120X ○ 10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	6	Poppet head	055/0127	0
9 Poppet stem assembly 055/0120X ○ 10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	7	RTFE main seal	5005-825	<u> </u>
10 M16 full nut (8) 5112-003 ○ 11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 ○ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○	8	Neoprene O ring	5005-995	<u> </u>
11 M16 spring washer (8) 5113-012 12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	9	Poppet stem assembly	055/0120X	0
12 Body weld assembly 055/0207 13 Top spring locator *Note 055/0116X 14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 1/4" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	10	M16 full nut (8)	5112-003	0
13 Top spring locator *Note 055/0116X  14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX  18 Bottom spring locator *Note 055/0110X  19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031  26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190  30 PTFE seal (supplied separate) 5005-812  31 89mm burst disc (supplied separate) 864/XXXX  32 Burst disc support flange 044/1034  33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	11	M16 spring washer (8)	5113-012	
14 Spindle guide bush 055/0115 □ ○ 15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	12	Body weld assembly	055/0207	
15 Stop collar 055/0125 ○ 16 Retaining ring clip 055/0114 □ ○ 17 Spring pair *Note 8104-XXXX 18 Bottom spring locator *Note 055/0110X 19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	13	Top spring locator *Note	055/0116X	
16       Retaining ring clip       055/0114       □ ○         17       Spring pair *Note       8104-XXXX         18       Bottom spring locator *Note       055/0110X         19       Spring retainer       055/0020       ○         20       M16 stud (8)       055/0055       ○         21       M6 set screw       5111-133       ○         22       Ferrule       SF1.5       ○         23       Anti-tamper wire       6110-119       ○         24       PTFE gasket       5005-826       □ ○         25       11mm ball       055/0031         26       Spring       5104-115       ○         27       Ball seal       055/0030       ○         28       ¼" BSP taper plug       5128-009       ○         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       ○         34       Anti-rotation tab (5)       055/0025       ○	14	Spindle guide bush	055/0115	<b>□</b> 0
17       Spring pair *Note       8104-XXXX         18       Bottom spring locator *Note       055/0110X         19       Spring retainer       055/0020       ○         20       M16 stud (8)       055/0055       ○         21       M6 set screw       5111-133       ○         22       Ferrule       SF1.5       ○         23       Anti-tamper wire       6110-119       ○         24       PTFE gasket       5005-826       □ ○         25       11mm ball       055/0031         26       Spring       5104-115       ○         27       Ball seal       055/0030       ○         28       ¼" BSP taper plug       5128-009       ○         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       ○         34       Anti-rotation tab (5)       055/0025       ○	15	Stop collar	055/0125	0
18 Bottom spring locator *Note 055/0110X  19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031  26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190  30 PTFE seal (supplied separate) 5005-812  31 89mm burst disc (supplied separate) 864/XXXX  32 Burst disc support flange 044/1034  33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	16	Retaining ring clip	055/0114	<b>□</b> 0
19 Spring retainer 055/0020 ○ 20 M16 stud (8) 055/0055 ○ 21 M6 set screw 5111-133 ○ 22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	17	Spring pair *Note	8104-XXX	X
20       M16 stud (8)       055/0055       ○         21       M6 set screw       5111-133       ○         22       Ferrule       SF1.5       ○         23       Anti-tamper wire       6110-119       ○         24       PTFE gasket       5005-826       □ ○         25       11mm ball       055/0031         26       Spring       5104-115       ○         27       Ball seal       055/0030       ○         28       ¼" BSP taper plug       5128-009       ○         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       ○         34       Anti-rotation tab (5)       055/0025       ○	18	Bottom spring locator *Note	055/0110X	
21       M6 set screw       5111-133       ○         22       Ferrule       SF1.5       ○         23       Anti-tamper wire       6110-119       ○         24       PTFE gasket       5005-826       □ ○         25       11mm ball       055/0031         26       Spring       5104-115       ○         27       Ball seal       055/0030       ○         28       ¼" BSP taper plug       5128-009       ○         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       ○         34       Anti-rotation tab (5)       055/0025       ○	19	Spring retainer	055/0020	0
22 Ferrule SF1.5 ○ 23 Anti-tamper wire 6110-119 ○ 24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	20	M16 stud (8)	055/0055	
24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	21	M6 set screw	5111-133	0
24 PTFE gasket 5005-826 □ ○ 25 11mm ball 055/0031 26 Spring 5104-115 ○ 27 Ball seal 055/0030 ○ 28 ¼" BSP taper plug 5128-009 ○ 29 Burst disc holder 055/0190 30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 ○ 34 Anti-rotation tab (5) 055/0025 ○	22	Ferrule	SF1.5	0
25       11mm ball       055/0031         26       Spring       5104-115       O         27       Ball seal       055/0030       O         28       ¼" BSP taper plug       5128-009       O         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       O         34       Anti-rotation tab (5)       055/0025       O	23	Anti-tamper wire	6110-119	0
26         Spring         5104-115         O           27         Ball seal         055/0030         O           28         ¼" BSP taper plug         5128-009         O           29         Burst disc holder         055/0190           30         PTFE seal (supplied separate)         5005-812           31         89mm burst disc (supplied separate)         864/XXXX           32         Burst disc support flange         044/1034           33         8mm Belleville washer (40)         5113-020         O           34         Anti-rotation tab (5)         055/0025         O	24	PTFE gasket	5005-826	□ 0
27       Ball seal       055/0030       O         28       ¼" BSP taper plug       5128-009       O         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       O         34       Anti-rotation tab (5)       055/0025       O	25	11mm ball	055/0031	
28       ¼" BSP taper plug       5128-009       O         29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       O         34       Anti-rotation tab (5)       055/0025       O	26	Spring	5104-115	0
29       Burst disc holder       055/0190         30       PTFE seal (supplied separate)       5005-812         31       89mm burst disc (supplied separate)       864/XXXX         32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       O         34       Anti-rotation tab (5)       055/0025       O	27	Ball seal	055/0030	0
30 PTFE seal (supplied separate) 5005-812 31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 O 34 Anti-rotation tab (5) 055/0025 O	28	1/4" BSP taper plug	5128-009	0
31 89mm burst disc (supplied separate) 864/XXXX 32 Burst disc support flange 044/1034 33 8mm Belleville washer (40) 5113-020 O 34 Anti-rotation tab (5) 055/0025 O	29	Burst disc holder	055/0190	
32       Burst disc support flange       044/1034         33       8mm Belleville washer (40)       5113-020       O         34       Anti-rotation tab (5)       055/0025       O	30	PTFE seal (supplied separate)	5005-812	
33 8mm Belleville washer (40) 5113-020 O 34 Anti-rotation tab (5) 055/0025 O	31	89mm burst disc (supplied separate)	864/XXXX	
34 Anti-rotation tab (5) 055/0025 O	32	Burst disc support flange	044/1034	
	33	8mm Belleville washer (40)	5113-020	0
35 Hex bolt (10) 5111-011 O	34	Anti-rotation tab (5)	055/0025	0
	35	Hex bolt (10)	5111-011	0

**NOTE**: The top and bottom spring locators and the spring pair are a set with compatible dimensions. Please contact Fort Vale if you need to replace one of these parts.

#### **Seal Kit**

Description	Part No.
All parts marked ☐ in the Parts List	005/00SK

#### Repair Kit

Description	Part No.
All parts marked O in the Parts List	015/00RK



#### 80mm Internal Gas Relief Valve (Cutaway Flange)

Part No: 016/2XXXX6 - Metric Setting



#### **Specification**

Nominal size

**DN80** 

Tank connection

Flanged: 8 x 18mm holes on a 184.2mm PCD

Set pressure

From 6.90 Bar to 34.80 Bar

**Materials** 

Contact parts: 316 stainless steel

Pressure seal: RTFE Tank seal: PTFE

Alternatives are available, refer to the Design Options page

#### **Design Conditions**

Weight: 11.4 Kg
Design Pressure (MAWP): 34.8 Bar
Test Pressure: 52.24 Bar
Design Temperature Min: -40°C
Design Temperature Max: 65°C

**NOTE:** The Design Temperature limits refer to metal parts only. The Design Conditions and Section View dimensions are for the specified part number only.

**Design Codes** BS EN 14129

Obeys TPED, ADR, UKCA


**Design Approval** 

LRQA

#### **Related Parts**

Description	Part No.
PTFE gasket	5005-826

#### **Section View**






#### 80mm Internal Gas Relief Valve (Cutaway Flange)

Part No: 016/2XXXX6 - Metric Setting

#### **Parts Drawing**



#### **Parts List**

Item	Description	Part No.	
1	M20 lock nut	5112-036	0
2	Cowl retaining washer	055/0135	0
3	Cowl	055/0130	0
4	M20 full nut	5112-033	0
5	M20 spring washer	5113-016	
6	Poppet head	055/0127	0
7	RTFE main seal	5005-825	0
8	Neoprene O ring	5005-995	0
9	Poppet stem assembly	055/0120X	0
10	Body weld assembly	055/0207	
11	Spindle guide bush	055/0115	0
12	Stop collar	055/0125	0
13	Retaining ring clip	055/0114	0
14	PTFE gasket (supplied separate)	5005-826	
15	Top spring locator *Note	055/0116X	
16	Spring pair *Note	8104-XXXX	
17	Bottom spring locator *Note	055/0110X	
18	Spring retainer	055/0020	0
19	M6 set screw	5111-133	0
20	Ferrule	SF1.5	0
21	Anti-tamper wire	6110-119	0

**NOTE**: The top and bottom spring locators and the spring pair are a set with compatible dimensions. Please contact Fort Vale if you need to replace one of these parts.

#### **Seal Kit**

Description	Part No.
All parts marked ☐ in the Parts List	006/00SK

#### Repair Kit

Description	Part No.
All parts marked O in the Parts List	016/00RK



# **Gas Discharge Valve Assembly**









#### **Gas Discharge Valve Assembly: T50 Tank Containers**

**Design Options** 

#### **Function**

The short profile discharge assembly is a compact internal valve with a secondary ball valve and tertiary closure. Two similar valve assemblies are installed on the tank, one connected to the liquid space and one to the vapour space. They operate on a pilot/main closure system so that they are easy to operate manually to control the loading and discharge of cargo.


The internal valve has an excess flow function. This is a safety feature to close the valve poppet if there is a sudden change to normal operating conditions, for example if there is a surge in the flow of cargo, or if there is a catastrophic leak in the downstream equipment.

The liquid and vapour phase valves are usually connected by a linkage mechanism so that they operate simultaneously.


#### **Design Options**

The design options below are available on our standard range of discharge assemblies for T50 tank containers.

Please contact us for more information about valve options.









#### Gas Discharge Valve Assembly: T50 Tank Containers

**Design Options** 

#### **Related Parts**

We recommend our range of compatible accessories:

- Footvalve handle linkage mechanisms
- Emergency remote closure systems and fusible elements
- Couplings, caps and plugs
- Gaskets
- **Fasteners**

Please contact us for more information about these parts.

#### **Footvalves for Dedicated Service**

We offer a range of footvalves and discharge systems for these service conditions and special cargoes:

- T50 tank containers for liquefied gas
- Rail tank wagons
- Offshore fuel and chemical tanks
- Road tankers carrying hot product (bitumen)
- Road tankers: top operated screwdown valve
- Hygienic service

Please contact us for more information about these valves.



#### 2" Short Profile Gas Discharge Valve Assembly

Part No: 802B/0010X



#### **Specification**

Nominal size/body angle

DN50 / 180°

Inlet connection

Flanged: 4 x 18mm holes equi-spaced on a 125mm PCD

**Outlet connection** 

ACME threaded outlet with cap

**Properties** 

Excess flow footvalve with ball valve, ACME outlet & cap

NOTE: You must install a separate tension spring to

emergency-close the footvalve

**Materials** 

Contact parts: 304/316 stainless steel

Footvalve main seal: PTFE Ball valve main seal: RTFE

Cap seal: PTFE

Alternatives are available, refer to the Design Options page

#### **Design Conditions**

Weight: Liquid/Vapour Phase
Design Pressure (MAWP):
Test Pressure:
Design Temperature Min/Max:
18.8 Kg / 17.9 Kg
34.5 Bar
70.0 Bar
-55°C / 80°C

**NOTE:** The Design Conditions and Section View dimensions are for the specified part number only.

#### **Design Codes**

BS EN 14432

BS EN 14433

BS EN 13445

Obeys TPED, ADR, UKCA


#### **Design Approval**


LRQA

#### Range

Description	Part No.
Liquid phase valve, 3¼" ACME outlet, left hand operation	802B/0010L
Vapour phase valve, 13/4" ACME outlet, right hand operation	802B/0010R

#### **Section View: Liquid Phase**








#### 2" Short Profile Gas Discharge Valve Assembly

Part No: 802B/0010X

#### Parts Drawing: Liquid Phase





#### 2" Short Profile Gas Discharge Valve Assembly

Part No: 802B/0010X

#### **Parts List**

Pari	Parts List			
Item	Description	Part No.		
1	M10 locking nut	5112-008		
2	M10 washer	5113-009		
3	Handle	370/3306		
4	Disc spring (3)	5113-038	•	
5	M6 hex head bolt (4)	5111-022		
6	M6 spring washer (4)	5113-008		
7	Clamp plate	370/3305B	•	
8	Neoprene O ring	5005-216		
9	Neoprene O ring	5005-866N		
10	Spindle bush	370/3307B		
11	Spindle seal	359/2007		
12	Bottom bush	370/3321		
13	Spindle	370/3320	•	
14	Body seal	370/3303		
15	PTFE ball seal (2)	370/3302		
16	50mm ball	370/3301		
17	M12 stud (4)	370/3314		
18	Footvalve body: LH liquid phase Footvalve body: RH vapour phase	252/5065L 252/5065R		
19	RTFE bearing pad	252/0580	0	
20	Push stem	252/0525/1	0	
21	Poppet spring	5104-826		
22	Push stem guide bush	252/0565	□ 0	
23	Spring location washer	252/0511		
24	M5 sockethead capscrew (3)	5111-118		
25	PTFE main seal	252/0563	□ 0	
26	Poppet head	252/0586		
27	Pilot seal retainer	252/0579/1	0	
28	M6 castle nut	5112-094	0	
29	Split pin (2)	5118-055	0	
30	Pilot seal	252/0583	0	
31	Spindle guide bush	252/0589	0	
32	Seal clamp	252/0588		
33	Liquid phase spring Gas phase spring	5104-824L 5104-821G		
34	Spider stem guide	252/3165		
35	Bottom spring pad	252/0526	0	
36	Bottom guide bush	252/0506B	<u> </u>	
37	Spindle	252/0504	0	
38	Bottom stem seal	359/4007	0	
39	Spacer ring	252/0512	0	
40	Top seal bush	252/0507	0	
41	Neoprene O ring	5005-217	□ 0	
42	Neoprene O ring	5005-216	□ 0	
43	Handle assembly	252/3520		
44	M6 hex head bolt (3)	5111-022		
45	M6 countersunk screw	5111-018		
46	Retaining washer	20370		

#### **Parts List**

Item	Description	Part No.	
47	Stuffing plate	252/5058B	
48	Split bearing	252/0517	
49	Top guide bush	252/0502B	
50	Top gland seal	359/4013	
51	Spacer ring	359/4012	0
52	Operating cam	252/0527	
53	M10 washer	5113-009	
54	M16 full nut (4)	5112-003	
55	M16 spring washer (4)	5113-012	
56	M12 spring washer (4)	5113-010	
57	M12 full nut (4)	5112-006	
58	Ball valve body	370/3368	
59	CNAF/PTFE gasket	5005-726	
60	Outlet: 31/4" ACME Outlet: 13/4" ACME	252/2069 252/2084	
61	PTFE seal: 3¼" ACME PTFE seal: 1¾" ACME	5005-877 5005-878	•
62	Plug: 31/4" ACME Plug: 13/4" ACME	252/2076 252/2086	
63	Dust cap: 31/4" ACME Dust cap: 13/4" ACME	252/2075 252/2085	
64	Retaining ring clip: 3¼" ACME Retaining ring clip: 1¾" ACME	5120-027 5120-028	
65	M16 hex head bolt (4)	5111-090	

#### **Seal Kit**

Description	Part No.
Ball valve seal kit: All parts marked ☐ in the Parts List	370/33SKB
Footvalve seal kit: All parts marked ☐ in the Parts List	252/50SKB

NOTE: The seal kits are compatible with liquid phase and vapour phase valves

#### Repair Kit

Description	Part No.
Ball valve repair kit: All parts marked ● in the Parts List	370/33RKB
Footvalve repair kit: All parts marked O in the Parts List	252/50RKB

NOTE: The repair kits are compatible with liquid phase and vapour phase valves



### **Accessories**





#### **ACME Outlet Assemblies**

#### **Accessories & Spare Parts**





#### **Specification**

The ACME outlet assembly is a tertiary closure system for liquefied gas discharge assemblies. It includes a spigot flange and a plug/cap assembly with a PTFE seal and retaining wire.

#### **Nominal sizes**

DN25, 1¾" ACME thread: compatible with vapour phase DN50, 3¼" ACME thread: compatible with liquid phase

#### Connection

4 x 18mm holes on a 125mm PCD

#### **Properties**

1/4" NPT connection for a sample/bleed valve or a pressure gauge. Safety bleed hole in the spigot.

#### **Materials**

Metal parts: 316 stainless steel

Seal: PTFE

#### **Design Conditions**

Design Pressure (MAWP): 34.5 Bar Test Pressure: 70.0 Bar Design Temperature Min: -50°C Design Temperature Max: 80°C


#### Range


Description	Part No.
DN25 13/4" ACME thread	252/2187
DN50 31/4" ACME thread	252/2177

#### **Spare Parts**


Item	Description	Part No. 1¾" ACME	Part No. 31/4" ACME
1.	Outlet flange	252/2084	252/2069
2.	ACME cap	252/2085	252/2075
3.	ACME plug	252/2086	252/2076
4.	Retaining ring clip	5120-028	5120-027
5.	PTFE seal	5005-878	5005-877
6.	Retaining wire	425/0009	425/0004


#### Section View - 13/4", Part No. 252/2187





#### Section View - 31/4", Part No. 252/2177








#### **Burst Discs**

#### **Accessories & Spare Parts**





#### **Specification**

Our range of non-fragmenting burst discs is compatible with Fort Vale relief valves and accessories. If you have other manufacturer's equipment, please contact us.

**WARNING**: A burst disc decreases the air flow capacity of a relief valve. Calculate to make sure that the decreased flow will give sufficient protection to your tank/system. Refer to Fort Vale for more information.

#### **Nominal sizes**

65mm XL, 80mm XL, 89mm, 250mm
Other sizes are available, please contact us.

NOTE: 65mm XL/80mm XL discs replace the original 65mm/80mm discs. We do not recommend 65mm/80mm discs with Fort Vale relief valves.

#### **Disc options**

Forward Acting: a cross-scored solid metal disc Forward Composite: a multi-layered disc for burst settings of less than 3.67 Bar

Reverse Acting: compatible with gas service

#### **Materials**

65XL/80XL/89mm: PTFE/316 stainless steel/Nickel

250mm: PTFE/316 stainless steel

Other materials are available, refer to next page.

#### 65mm XL Burst Discs

Compatible with general purpose tank containers and road tankers.

Burst Pressure Bar	Burst Temperature °C	Part No.
2.28	20	862/X0228020B
2.41	20	862/X0241020B
2.69	20	862/X0269020B
3.10	20	862/X0310020B
3.67	20	862/X0367020A
4.10	20	862/X0410020A
4.40	20	862/X0440020A
4.84	20	862/X0484020A

**NOTE**: The specification changes the part no.

#### 89mm Reverse Acting Burst Discs

Compatible with compressed liquefied gas tank containers.

Burst Pressure Bar	Burst Temperature °C	Part No.
12.10	55	864/X1210055GX
15.00	55	864/X1500055GX
22.00	55	864/X2200055GX
27.50	55	864/X2750055GX
34.50	55	864/X3450055GX

NOTE: The specification changes the part no.

#### 80mm XL Burst Discs

Compatible with general purpose tank containers and road tankers.

Burst Pressure Bar	Burst Temperature °C	Part No.
3.67	20	864/X0367020A
4.10	20	864/X0410020A
4.84	20	864/X0484020A

**NOTE**: The specification changes the part no.

#### 250mm Standard Burst Discs

Compatible with hydrogen peroxide service.

Burst Pressure Bar	Burst Temperature °C	Part No.
4.50	20	865/A0450020AD
4.50	60	865/A0450060AD
6.00	20	865/A0600020AD



#### Part Number Code: 65mm XL, 80mm XL, 89mm Only

**Accessories & Spare Parts** 

		Example:	8	6	X	1	X	04	84	020	) X	
											_	
Disc S	ize ————											
862/ 864/	65mm XL 80mm XL or 89mm Reverse Acting											
Disc N	lanufacturer —											
A B C	CDC (Continental Disc Corporation) BS&B Safety Systems Schlesinger											
Burst	Pressure in kPa											
0484	484 kPa (4.84 Bar)											
Burst	Temperature in °C —————											
020	20°C											
Disc T	уре ———											
A B G	Forward Acting (ICON) Forward Composite (PC-SERT) Reverse Acting: Gas service											
Specia	Il Material/Service: Disc Type A & E	B Only —										
Note: 1 2 3 4 5 6 7 8 9 A B C D E	No number = Standard Material/Service PFA Lined PTFE Lined Tantalum Alloy 600 Oxygen Cleaned High Temperature 250° Titanium Standard 30° Angle Monel ® Inconel ® / 316TI Nickel Hastelloy ® C276 Standard + Handling Support Monel ® Fluoro Coated	ce										
Specia	ıl Material/Service: Disc Type G Or	nly ———										
Note: 1 2	No number = Standard Material/Servic Hastelloy ® / PTFE Monel ®	ce										

6 Monel ® 400 / Sigma ® 500

Tantalum

Alloy 400

Alloy 600

3

4

5



#### **Pressure Gauges**

#### **Accessories & Spare Parts**

#### **Standard Pressure Gauge**



**Tell-Tale Pressure Gauge** 



#### **Specification**

We supply standard pressure gauges and tell-tale pressure gauges. Tell-tale pressure gauges have a secondary pointer to indicate if there has been an increase in pressure, even if the pressure subsequently decreases

All pressure gauges have a ¼" BSP bottom connection and are glycerine filled.

Pressure range options 0-6 Bar, 0-10 Bar, 0-16 Bar, 0-40 Bar Material options - internal parts Brass, stainless steel

#### **Standard Pressure Gauge**

Pressur Bar	e Range PSI	Internal Parts	Part No.
0-6	0-90	Brass	921/06BBSP
0-6	0-90	St/steel	920/06BBSP
0-10	0-150	Brass	921/10BBSP
0-10	0-150	St/steel	920/10BBSP
0-40	0-580	St/steel	920/40BBSP

#### **Tell-Tale Pressure Gauge**

Pressure Range Internal Parts Par	rt No.
Bar PSI	
0-6 0-90 Brass 921	1/06TTBBSP
0-6 0-90 St/steel 920	0/06TTBBSP
0-10 0-150 Brass 921	1/10TTBBSP
0-10 0-150 St/steel 920	D/10TTBBSP
0-16 0-230 St/steel 920	D/16TTBBSP
0-40 0-580 St/steel 920	0/40TTBBSP



# **APPENDIX**

#### Catalogue

A	Bolt Torque Guide & Step Loading Procedure
В	Client Responsibilities - Valves & Accessories



#### **Bolt Torque Guide & Step Loading Procedure**

#### **Installation & Operating Instructions**

#### Flange Bolting

CAUTION: Weld-distortion and too much tightening force will cause damage to a flange.

It is important not to cause damage to weld-in flanges and mating flanges. If a flange is damaged it will not give a satisfactory seal when a gasket and secondary mating flange is installed.

Bolt-stress can decrease after initial tightening. The cause can be deformation of the gasket material, particularly with soft materials such as a CNAF/PTFE envelope gasket.

Best procedure recommends that, after initial bolting, the flange joint is tightened again after a period of time. Most gasket manufacturers advise a period of 24 hours. ASME PCC-1-2000 GUIDELINES FOR PRESSURE BOUNDARY BOLTED FLANGE JOINT ASSEMBLY advises a minimum period of 4 hours.

Bolt torque calculations are based on a flat flange to within 0.15mm.

Recommended bolt torque values will be reduced if a lubrication is used.

#### **Bolt Torque**

#### **Bolt Torque Values**

Fort Vale bolt torque values are given as a reference guide only and are based on:

- · the use of a CNAF/PTFE gasket.
- · unlubricated fasteners.
- a flange flat to within 0.15mm.

**CAUTION:** If you use a different gasket material, a lubricant or a flange with distortion, you must re-calculate the torque value.

#### **Bolt Torque Procedure**


To install flanged parts correctly:

- · Examine the mating flange of the part.
- If the flange is marked with a torque value, obey that torque value.
- If there is no torque value marked on the mating flange, obey the bolt torque values given in Table BT1.
- Tighten the bolts evenly in sequence. Refer to Figure BT1.
- Obey the Step Loading Procedure (ASME PCC-1-2000). Refer to the next page.


#### Table BT1

Thread	Torque Value
M10	30 Nm (22 lbf.ft)
M12	65 Nm (48 lbf.ft)
M16	81 Nm (60 lbf.ft)


#### Figure BT1



**8 HOLE PATTERN** 



**6 HOLE PATTERN** 



**4 HOLE PATTERN** 

 www.fortvale.com
 Page 1 of 2
 OPIN\_STEP
 REV05-24.08.21

 © Fort Valle Engineering Ltd. 2019
 27
 CAT\_GAS\_REV02



#### **Bolt Torque Guide & Step Loading Procedure**

#### **Installation & Operating Instructions**

#### **Step Loading Procedure**

To install flanged parts correctly, obey the Step Loading Procedure extract from ASME PCC-1-2000:

#### Install

Hand tighten, then "snug up" to 15 Nm (10 lbf.ft) to 30 Nm (20 lbf.ft) (not to exceed 20% of Target Torque). Check flange gap around circumference for uniformity. If the gap around the circumference is not reasonably uniform, make the appropriate adjustments by selective tightening before proceeding.

#### Round 1

Tighten to 20% to 30% of Target Torque. Check flange gap around circumference for uniformity. If the gap around the circumference is not reasonably uniform, make the appropriate adjustments by selective tightening before proceeding.

#### Round 2

Tighten to 50% to 70% of Target Torque. Check flange gap around circumference for uniformity. If the gap around the circumference is not reasonably uniform, make the appropriate adjustments by selective tightening before proceeding.

#### Round 3

Tighten to 100% of Target Torque. Check flange gap around circumference for uniformity. If the gap around the circumference is not reasonably uniform, make the appropriate adjustments by selective tightening before proceeding.

#### Round 4

Continue tightening the bolts, but on a rotational clockwise pattern until no further nut rotation occurs at the Round 3 Target Torque value. For indicator bolting, tighten bolts until the indicator rod retraction readings for all bolts are within the specified range.

#### Round 5

Time permitting, wait a minimum of 4 hr and repeat Round 4; this will restore the short-term creep relaxation/embedment losses. If the flange is subjected to a subsequent test pressure higher than its rating, it may be desirable to repeat this round after the test is completed.



#### Client Responsibilities - Valves & Accessories

#### **Installation, Operation & Maintenance Instructions**

#### Compatibility

Make sure that the function and technical specification of the valve/accessory is compatible with the vessel service conditions and the cargo. This includes, but is not limited to:

- · dimensions.
- pressure/vacuum setting.
- air/vapour/liquid flow capacity.
- maximum allowable working pressure.
- · test pressure.
- · minimum/maximum design temperatures.
- materials of construction.

#### Maintenance and Inspection

Fort Vale valves and accessories have a long life if you use them correctly in compatible service conditions. It is not necessary to lubricate the parts, but we recommend that you do the inspections that follow:

#### Inspections at regular intervals:

- 1. Examine the valve to make sure there is no damage, wear or corrosion.
- 2. Examine the valve and adjacent area to make sure there is no leakage of cargo.
- 3. Examine the fasteners to make sure they are not loose.
- 4. Make sure the valve operates correctly.

**CAUTION**: If you operate the valve with very corrosive cargo, or near its temperature and/or pressure limit (very high or very low temperature and/or pressure), do the inspections more frequently.

Also, schedule regular maintenance based on how frequently the valve is used, the type of cargo and the service conditions.

#### Inspections after 21/2 years of service or a minor incident:

- 1. Examine the valve to make sure there is no damage, wear or corrosion.
- 2. Make sure the valve operates correctly.
- 3. Do a pressure test on the valve.

#### Inspections after 5 years of service or a major incident:

- 1. Disassemble and clean the valve.
- 2. Replace all the valve seals and do a pressure test.

#### **Replacement Parts**

Do not adapt or change the valve. If you install a replacement part, it must be a genuine Fort Vale part.

WARNING: If you install a part that is not genuine, there is a risk of:

- · injury to personnel.
- permanent damage to the valve.
- · permanent damage to the vessel.
- valve malfunction.

#### **External Fire**

If you install the valve in an area where there is a risk of external fire, you must install compatible accessories to prevent damage to the valve.

#### **Compatibility of Accessories**


Accessory components must cause no interference with the valve's function. Accessories must be made from compatible materials that will cause no damage to the valve materials. Do not install an accessory that will cause an increased load on the valve, such as mechanical, static, dynamic or thermal load.

#### Mis-use

Obey the instructions and recommended procedures in the installation and operating instructions. Obey the pressure and temperature markings on the valve and on the drawing. Use the valve/accessory for its correct function only. Fort Vale accept no liability or responsibility for incorrect use of the valve/accessory.



#### Our subsidiaries are located in:



We also have Authorised Distributors around the world to provide you with product sales and after-market services. To find your nearest distributor, please visit our website - **www.fortvale.com** 





UK • USA • NETHERLANDS • CHINA • SINGAPORE • AUSTRALIA